



## **CTT™ -EC TABLETS**

### **Evaporative Cooler Treatment**

[Description](#) | [Characteristics](#) | [Applications](#) | [Packaging](#) | [Instructions](#) | [Precautions](#) | [Specifications](#) | [Limited Warranty](#)

#### **DESCRIPTION:**

---

CTT™ - EC Tablets, by placement in the reservoir, automatically provide water treatment proportionate to operating conditions without feeder equipment. They prevent hard water mineral scale, ferrous and non-ferrous corrosion, and silt and soil accumulations in evaporative coolers. Preventing these problems improves efficiencies, reduces break-downs, and decreases power costs.

[Top of Page](#)

#### **CHARACTERISTICS:**

---

- Automatic water treatment
- Keeps filter clean
- Easy to use
- Improves efficiencies
- Decreases power costs
- Reduces break-downs

[Top of Page](#)

#### **APPLICATIONS:**

---

CTT™ - EC Tablets provide water treatment for evaporative coolers. Tablets are easy to use; just put in and walk away.

[Top of Page](#)

**PACKAGING:**

---

Code	Size	Qty. Per Case	Lbs. per Case	Cu. Ft Per Case
68030	4 tablet tube	12	9	0.24
68028	300 tablet pail	1	43	1.25

[Top of Page](#)

**INSTRUCTIONS:**

---

Add one tablet to reservoir for every 3,000 gallons of water evaporated from the system. Add more tablets as needed. For best results, first clean and flush dirty systems.

For additional technical information, call Toll Free 1-800-231-3345.

[Top of Page](#)

**PRECAUTIONS:**

---

FOR CHEMICAL EMERGENCY, SPILL, LEAK, FIRE, EXPOSURE OR ACCIDENT,  
CALL CHEMTREC - DAY OR NIGHT 1-800-424-9300

**CONTAINS: Sodium Silicate. PRECAUTIONS:** May cause eye and skin irritation. Wear adequate protective gear and clothing. Avoid contact with eyes and skin. Wash after handling. **FIRST AID:** For any overexposure, get immediate medical attention after first aid is given. **Eyes** - Flush 15 minutes with clean water. **Skin** - Wash with soap and water. **Ingestion** - Only if conscious, give large amounts of water. Seek immediate medical attention. **KEEP OUT OF REACH OF CHILDREN.**

For additional information, refer to Material Safety Data Sheet.

[Top of Page](#)

**SPECIFICATIONS:**

---

Flash Point SETA CC	None
Color	Blue tablet
Shelf Life	2 years

Suggestions and recommendations covering the use of our products are based on our past experience and laboratory findings. However, as we have no control as to the methods and conditions of application, we only assume responsibility for the uniformity of our products within manufacturing tolerances.

[Top of Page](#)

### **LIMITED WARRANTY:**

---

RectorSeal® makes the Limited Express Warranty that when the instructions for storage and handling of our products are followed we warrant our products to be free from defects. THIS LIMITED EXPRESS WARRANTY IS EXPRESSLY IN LIEU OF ANY OTHER EXPRESS OR IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND OF ANY OTHER OBLIGATION ON THE PART OF RECTORSEAL®. The sole remedy for breach of the Limited Express Warranty shall be the refund of the purchase price. All other liability is negated and disclaimed, and RectorSeal® shall not be liable for incidental or consequential damages.

[Top of Page](#)

MANUFACTURED IN U.S.A. BY

**RectorSeal®**

2601 Spenwick Drive • Houston, TX 77055 USA

713-263-8001 • Fax 713-263-7577

Toll-free 800-231-3345 • Fax 800-441-0051

[Back](#)