

EZ TRAP®

U.S. Patent Numbers 5,069,042 5,522,229

Model No.

83180

(EZT 180)

Mini Waterless In-Line Condensate Trap

Kit Contents

- Mini Trap (1)
- Rubber Adaptor (1)
- Cleaning Label (1)



Scan for more info



3 YEAR WARRANTY. The manufacturer disclaims all implied and express warranties, including the implied warranty of merchantability and the implied warranty of fitness for a particular purpose, except as follows: The EZ-Trap condensate trap or overflow switch purchased by you is unconditionally warranted to be free from defects in material and workmanship under normal use for a period of three (3) years from date of purchase, providing it is installed and operated strictly in accordance with manufacturer's installation instructions. If the product is found to be defective or otherwise fails in normal use, you may return it for replacement. All freight charges for the return of the product shall be borne by you. The manufacturer will pay outgoing freight charges for the replacement product. Defective products returned to the factory prepaid will be repaired or replaced free of charge. Replacement product will, to the extent such product is then available in manufacturer's inventory, be of similar type, color and kind. Manufacturer retains the right to substitute product if replacement product does not conform in terms of color, type and specifications to the original product, if no longer available. This warranty does not cover replacement labor or any cost, claim or incident to any defect nor does it cover freezing or any other consequential damages. The sole liability of the manufacturer under this warranty is limited to the replacement of defective product. Product damaged by improper use, accident, neglect, alteration, abuse or improper installation is excluded from this warranty.

RectorSeal® 2601 Spenwick Drive - Houston, TX 77055
ph: 713.263.8001 - 800.231.3345 fax: 713.263.7577 - 800.441.0051
www.rectorseal.com - Like Us on Facebook

961735



83180 (EZT 180)

Instalation instructions / Instrucciones de instalación




Figure 1




Figure 2




Figure 3




Figure 4




Figure 5




Figure 6

1. Trap must be fitted at least 12" below indoor unit (**Figure 1**).
2. Ensure that Black Valve Assembly is perpendicular to or facing away from wall to facilitate cleaning.
3. For 5/8" (16mm) drain hose, insert end of upper drain hose into top of Trap (Wide End) and seat firmly (**Figure 2**).
4. For 9/16" (14mm) drain hose, insert Rubber Adaptor into top of Trap and insert hose into Adaptor and seat firmly (**Figure 3**).

CAUTION: TRAP MUST BE INSTALLED VERTICALLY – WIDE END UP AND NARROW END DOWN – FOR CONDENSATE TO FLOW. INCORRECT INSTALLATION WILL CAUSE BACK-UP OF CONDENSATE.

5. Insert bottom end of Trap (Narrow End) into top of lower drain hose (**Figures 4 & 5**).
6. Wrap inlet and outlet connection with PVC Tape (**Figure 6**).
7. Fit Hose/Trap assembly to wall with 2 pipe brackets 3" from Trap (**Figure 5**).

WARNINGS

1. **THIS TRAP IS DESIGNED FOR USE WITH NO-KINK CORRUGATED PE DRAIN HOSE (DH-16). THIN WALL VINYL HOSE KINKS VERY EASILY AND SHOULD NOT BE USED FOR THIS APPLICATION.**
2. **DO NOT INSTALL TRAP HORIZONTALLY**
3. **DRAIN HOSE EXITING UNIT MUST HAVE SLOPE TO FACILITATE CONDENSATE FLOW**

IMPORTANT NOTES

1. FOR USE WITH MINISPLIT AIR CONDITIONERS ONLY.
2. REMOVE TRAP BEFORE CLEANING COOLING COIL WITH CHEMICAL CLEANER.
3. DO NOT GLUE THIS TRAP.
4. WHERE POSSIBLE, INSTALL WITHIN 6' OF GROUND TO FACILITATE INSPECTION AND CLEANING.
5. TRAP IS NOT REQUIRED IF CONDENSATE PUMP IS FITTED.
6. CLEAN AT LEAST ONCE ANNUALLY OR MORE OFTEN IF REQUIRED.
7. ENSURE THAT BLEED HOLES ARE NOT BLOCKED.
8. THIS DEVICE MUST BE INSTALLED STRICTLY IN ACCORDANCE WITH MANUFACTURER'S INSTRUCTIONS TO ENSURE PROPER OPERATION AND IN ACCORDANCE WITH ALL APPLICABLE LOCAL PLUMBING, DRAINAGE AND/OR MECHANICAL CODES.